

Installation Step 1: Removing the bottom front under-engine plastic belly-pan/fairing (three bolts and ~13 standard Subaru rivet fasteners). An interior/upholstery fastener removal tool is a great tool to have along with a metric socket ratchet set. Using the rear-center bolt 1st, is helpful in reinstalling the fairing as you button-up the vehicle. Slide the fairing under the front bumper lip, hold it in place with one hand and screw in the rear center bolt, and then take your time reinstalling the remaining multitude of plastic rivets/bolts.

Once the bottom fairing is removed, locate the front corner bracket mounting areas and remove the one OEM bolt used to assist in mounting the bar mounting brackets... insert the pair of supplied long bolts from the top of the sub frame, the pair (one each side) bolts through the chassis sub-frame holes, there is also a supplied pair of square u-brackets that drop over the sub.







