

UNIVERSAL FLAT ALUMINIUM CARGO BASKET INSTALLATION MANUAL



corner (4x)



Socket head screw (8x)



The cross screw (32x)



T30 wrench (1x)



1. Install corners and connect the corners to the frame.



2. Assemble the other three corners in turn.



3. Install the bottom plate, match the bottom plate to the hole of the frame, and fix it with screws.



4. The installation is complete.



5. Slide the accessories into the base plate, adjust the frame and crossbeam to a proper position, and then lock them with screws



6. Installation effect display.