



Optimus Contour Series Installation



Place the iron tabs on the top and bottom of the trailer hitch and secure with screws



